

Operation & Installation Manual

CONTENT

Parts and Functions	1
Operation	7
Wired Controller Wiring Instruction.....	26


Ver: A

- Please read this operation manual before using the wired controller.
- Please keep this manual carefully and safely.








Parts and Functions

Interface Display







Parts and Functions













Key

	Fan speed adjustment key in the main interface, return key in other interface.
	Menu key in the main interface, set key in other interface.
	Press this key to adjust temperature in the main Interface and other parameter value in other interface. And the key is also used for function switching.
	Mode key in the main interface, OK key in other interface.
	On/Off key.
















Icon

	Child Lock: This icon will be displayed only when child lock function is set.
	Error icon
	Filter Cleaning
	Timer ON/OFF

Parts and Functions

	VIP
	Mode conflict
	Lock/Central
	Wi-Fi icon
	Left/Right Swing (Only valid for part of models)
	Four-way cassette swing (Only valid for part of models)
	Up/Down Swing
	Motion sensing
	Motion sensing follow
	Motion sensing evade
	ROOM /SET temperature display
	Auto mode

Parts and Functions

	Cooling mode
	Dry mode
	Heating mode
	Fan mode
	Fan speed
	Quiet: This icon will be displayed only when quiet function is set.
	Turbo: This icon will be displayed only when turbo function is set.
	Sleeping: This icon is displayed when sleeping is set, and remaining time of sleeping is displayed by  OFF  .
	Self-cleaning
	Heat Reclaim Ventilation
	Heater
	Energy Saving: This icon will be displayed only when energy saving function is set.
	Health : This icon will be displayed only when health function is set.

Parts and Functions



LED on panel

Note: Each function is usually only applicable to some models.

Fan speed




(1) fan speed(only valid for part models)	
♪	Breeze Fan Speed
♪	Low Fan Speed
♪	Medium Fan Speed
♪	High Fan Speed
♪	Super Fan Speed
^{AUTO} ♪	Auto Fan Speed

Parts and Functions

(2) fan speed(only valid for part models)	
☸	Seven gear
☸	Sixth gear
☸	Fifth gear
☸	Fourth gear
☸	Third gear
☸	Second gear
☸	First gear
<small>AUTO</small> ☸	Auto





Operation

Initialization

(1) The wired controller will display all the icons after being powered on or reset, then it gets into the initializing process. The controller will display in sequence as follows :  (middle of the top) →  →  (middle of the top), the indicator light (the bottom-right corner) flashes all the time until the initialization ends.

(2) If the wired controller can't communicate with the indoor unit PCB normally after powering on, the initialization will be finished in 4 minutes, and then the communication malfunction can be checked from the malfunction inquiry function.

Backlight time






















(1) In the state of off , when the backlight is lit up, long press  key and  key for 5 seconds to set backlight time, the parameter value is displayed in the upper left corner. Press  or  key to switch parameter between 00(means backlight always on)/15S/30S/60S and confirm by pressing the Mode key.

(2) The backlight time is fixed for 15 seconds when the controller is turned off.

Operation

Extra function



Press MENU key to enter function circulation, use + or - key to switch between different functions. The function circulation is as follows (functions that are not valid for some models do not participate in the circulation, please refer to the function description of the indoor unit):

 (Up/Down swing) →  (four-way cassette swing) →  (Left/Right swing) →  (Filter cleaning, Only participate in the circulation when there is a filter reminder) →  (ON/OFF)  (Timer) →  (Quiet) →  (Turbo) →  (Sleeping) →  (Self-cleaning) →  (HRV) →  (Heater) →  (Energy saving) →  (Health) →  (LED on panel) →  (Motion sensing) →  (Motion sensing follow) →  (Motion sensing evade) →  (Health airflow up) →  (Health airflow down) → 10°C (10°C heating, Valid only in heating mode) →  (Up/Down swing)...

When you select a function, the corresponding icon flashes, then you can use MODE key to set/cancel function or use menu key enter the corresponding function setting interface.



Operation



Swing

(1) Press MENU key, you will enter function circulation, use + or — key to switch between different functions. Switch to the Up/Down swing  or Left/Right swing , then press MODE key to enter the setting of swing angle (only valid for part of models). At this time you can use + or — key to adjust the swing angle. After adjustment, press MODE key to exit the setting.

(2) After adjustment, if there is no operation within 10 seconds or press FAN key, it will quit swing setting interface and previous changes are valid.

Four-way cassette swing (Only valid for part of models)

(1) Four-way cassette swing, the icon  and the icon  will be displayed in the main interface.



(2) Press MENU key to function circulation, use + or — key to select the four-way cassette swing. Now, the deflector  and the angle  will be flashing at the same time.

Press MODE key to enter the setting of four-way cassette swing, and then press the MENU key to select the deflector 1,2,3,4 as well as the simultaneous control, use + or — key to adjust the swing angle, press MODE key to confirm and exit the settings.




(3) After adjustment, if there is no operation within 10 seconds or press FAN key, it will quit swing setting interface and previous changes are valid.

Operation



Filter Cleaning



When filter cleaning icon  is displayed, the icon will display in function circulation. Press MENU key to enter function circulation, use + or - key to switch between different functions. Switch to icon , press MODE key to cancel the display of icon .



Timer



- (1) Timer function includes Timer on, Timer off and Timer on/off.
- (2) Press MENU key to enter extra function, then you can press + or - key to timer setting  (ON/OFF)  . At this time, the icon  will flash, press MODE key to confirm and exit the settings.
- (3) If the state of the timer function is on, when you switch to the timer function in the function circulation, pressing MODE key to turn it off.

(4) when enter timer setting,  icon flashes, press MENU key to enter timer type.

 ON  (ON is flashing) →

 OFF  (OFF is flashing) →



 ON/OFF  (ON is flashing) →

 ON/OFF  (OFF is flashing) →

Press the menu key once to switch to one type, and use + or - key to adjust time parameters. Finally press MODE key confirm and exit the settings.


Operation

Quiet/ Turbo

(1) Press MENU key to function circulation, use $+$ or $-$ key to switch Quiet icon  or Turbo icon , press MODE key confirms and exit the settings.

(2) Quiet/ Turbo function cannot be set at the same time. When the latter function is set, the former will be automatically canceled.

Sleeping

(1) Press MENU key, you will enter function circulation, use $+$ or $-$ key to select Sleeping functions icon . Press MENU key to enter sleeping time setting, use $+$ or $-$ key to adjust the sleeping time by 0.5h once, the range of sleeping time is from 8h to 0.5h, press MODE key to confirm.

(2) When the sleeping time is up, the controller will turn off.



(3) If the state of the sleeping function is on, when you switch to the sleeping function in the function circulation, pressing MODE key to turn it off.

(4) If controller is turned off when the sleeping function is turned on, the sleeping function will be cancelled.



Operation

Self-cleaning

Note: Only valid for the units with self-cleaning function.


- (1) Press MENU key, you will enter function circulation, use $+$ or $-$ key to select self-cleaning function icon , press MODE key to confirm and exit the settings.
- (2) If the state of the self-cleaning function is on, when you switch to the self-cleaning function icon  in the function circulation, pressing MODE key to turn it off.
- (3) When the self-cleaning function is set, if you switch modes or switch ON/OFF, the self-cleaning function will be exit.
- (4) If you set timer or sleeping function, self-cleaning function does not participate in the function circulation. If self-cleaning function is turned on, timer and sleeping cannot be set.


Heat Reclaim Ventilation

- (1) Press MENU key, you will enter function circulation, use $+$ or $-$ key to select HRV icon . Switch to function, then press MODE key, HRV function will be turned on. If the function is turned on, icon will be displayed in the main interface.
- (2) When the HRV function is turned on, if you want to turn it off, please enter function circulation and switch to  icon, then press MODE key, and the function will be turned off.



Operation


Heater(Valid only in heating mode and auto mode)

(1) Press MENU key, you will enter function circulation, use \uparrow or \downarrow key to select Heater icon  , Switch to function, then press MODE key, Heater function will be turned on. If the function is turned on, icon will be displayed in the main interface.

(2) When the Heater function is turned on, if you want to turn it off, please enter function circulation and switch to  icon, then press MODE key , and the function will be turned off.

Energy saving


(1) Press MENU key, you will enter function circulation, use \uparrow or \downarrow key to switch between different functions. Switch to  Energy saving function, then press MODE key to confirm, energy saving function will be turned on. If the function is turned on,  icon will be displayed in the main interface.

When the energy saving function is set, press MENU key to enter function circulation and choose  , then press MODE key to exit energy saving function.

(2) If the energy saving function is turned on, the adjustment of the setting temperature of the cooling/dry/heating mode will be limited. The energy saving default parameters are 23°C (the lowest temperature limit of cooling and dry mode) and 26°C (the highest temperature limit of heating mode).

Operation



(3) The energy saving parameters can be changed :

Press MENU key, you will enter function circulation, use $+$ or $-$ key to switch between different functions. Switch to  Energy saving function. At this time, the icons of cooling and heating, as well as the energy saving parameters in cooling and heating modes, flash alternately.

Then press MENU key to enter energy saving parameter adjustment. First, enter the cooling energy saving parameter adjustment, the cooling icon flashes, use the $+$ or $-$ key to adjust the energy saving parameters, and press the MODE key to confirm.



After that, enter the heating energy saving parameter adjustment, the heating icon flashes, use the $+$ or $-$ keys to adjust the energy saving parameters, press the MODE key to confirm and exit the energy saving parameter adjustment.

Health




Press MENU key, you will enter function circulation, use $+$ or $-$ key to select health icon  , Switch to function, then press MODE key, health function will be turned on. If the function is turned on,  icon will be displayed in the main interface.


Operation

LED on panel (only valid for part of models)

Press MENU key, you will enter function circulation, use + or — key to select LED on panel icon  , Switch to function, then press MODE key, LED on panel function will be turned on. If the function is turned on,  icon will be displayed in the main interface.




Motion sensing (only valid for part of models)




(1) Motion sensing function includes:  (Motion sensing),  (Motion sensing follow),  (Motion sensing evade)

 If no one is perceived for half an hour(the time is depended on the indoor unit or the setting of move eye), the indoor unit will be off.

 Swing direction follows people

 Swing direction Evades people.

(2) Press MENU key, you will enter function circulation, use + or — key to select Motion sensing functions icon  /  /  , press MODE key confirms and exit the settings.

(3)  /  /  functions cannot be turned on at the same time. Only one function can exist at a time. When the latter function is set, the former will be automatically canceled.

Operation

Health airflow up/down function (only valid for part of models)

- (1) Press MENU key, you will enter function circulation, use \uparrow or \downarrow key to switch between different functions. Switch to \nearrow (health airflow up) or \nwarrow (health airflow down) function, then press MODE key to set the function. When the function is successfully set, the corresponding icon will be displayed on the main interface.
- (2) Health airflow up/down function cannot be set at the same time. When the latter function is set, the former will be automatically canceled.
- (3) When health airflow up/down function is set, if you adjust the swing angle, the health airflow up/down function will be canceled.

10°C heating(Valid only in heating mode)

- (1) Only in heating mode, this function is valid in function circulation.
- (2) Press MENU key, you will enter function circulation, use \uparrow or \downarrow key to switch between different functions. When it switches to the 10°C heating function, 10°C will flash in the temperature display area. Press MODE key to confirm.
- (3) In the state of the 10°C heating function, when you switch to the 10°C heating function in the function circulation, pressing MODE key to turn it off.
- (4) In the state of 10°C heating function, if you change modes or adjust temperature setpoint, you will exit the 10°C heating function.

Operation


Switch between Fahrenheit and Celsius

(1) If the current temperature is displayed in Celsius, adjust temperature in each mode to 30°C (when energy saving function is set currently, the parameter in heating mode will be the highest limit value). Then press \oplus key for 15s to switch to Fahrenheit, the interface will display 86°F (when energy saving function is set, its highest limit value of Fahrenheit will be displayed).

(2) If the current temperature is displayed in Fahrenheit, setting temperature should be adjusted to 60°F in each mode (when energy saving function is set currently, the parameter in cooling/dry mode will be the lowest limit value). Then press \ominus key for 15s to switch to Celsius, the interface will display 16°C (when energy saving function is set, its lowest limit value of Celsius will be displayed).

Malfunction Display

(1) If there is a malfunction, the main interface will display  icon.

(2) When backlight is on, long press  key for 5 seconds to enter malfunction display interface. The current malfunction code is displayed in the middle area, and the left part of the timer displays historical malfunction1, the right part of the timer displays the historical malfunction2. The lower right corner shows the unit number, you can use \oplus or \ominus key to switch it (if the controller controls multiple units).

Operation

- (3) In the state of viewing malfunction, long press FAN key for 5 seconds to clear the current malfunction and a historical malfunction.
- (4) If there is no malfunction, it will display “- -”.

Parameter inquiry

(1) Keep pressing MENU key for 5 seconds to enter parameter inquiry interface. The parameter value is displayed in the upper left corner, and middle area displays parameter type (use \oplus or \ominus key to switch it), and the unit number is displayed in the lower right corner (use menu key to switch it).

(2)

Type	Meaning	Parameter format
A	Indoor sensor Tai temperature	Decimal
b	Indoor sensor Tc1 temperature	Decimal
C	Indoor sensor Tc2 temperature	Decimal
d	Indoor unit PMV opening/2	Decimal
E	Indoor unit address	Hexadecimal
F	Indoor unit central address	Hexadecimal


Operation

Unit number setting

(1) Long press MENU key for 10 seconds to enter unit number setting interface. The left part of the timer displays communication address, the right part of the timer displays the central address, and the unit number is displayed in the middle area.

(2) If the communication address flashes, you can change it with $+$ or $-$ key, and the adjustment range is 0~3F. After adjustment, you need to press MODE key to confirm changes. If the communication address is static displayed, it cannot be changed.

Child lock

Press $+$ and $-$ keys for 5 seconds to set / cancel child lock. If child lock function is set,  icon will be displayed in the main interface. In the state of child lock, all keys are not available.

Operation

Static Pressure (only valid for part of models)

(1) When the controller is turned on, press FAN and MODE keys for 5 seconds to enter static pressure interface. The parameter of static pressure is displayed in the middle area. And you can use $+$ or $-$ key to adjust it. After adjustment, you need press MODE key to confirm changes. The unit number is displayed in the left part of the timer.

(2) The slave controller cannot set the static pressure function.

Low temperature dehumidification



(1) Long press MENU and $+$ keys for 5 seconds to enter advanced settings. The unit number is displayed in the lower right corner. Parameter is displayed in the upper right corner. Middle area displays function code. Press $+$ or $-$ key to switch to A38, and then press MODE key to enter parameter adjustment, use $+$ or $-$ key to adjust parameter to 1(turn on low temperature dehumidification), then press MODE key to confirm change. At this time, you can exit the advanced settings by no operation.

(2) After the low temperature dehumidification function is turned on, the range of setting temperature in dry mode is 10°C~30°C.

(3) If you want to cancel this function, please change the parameter of A38 to 0, then the range of setting temperature in dry mode is 16°C~30°C.

Operation

Communication with central controller

- (1) After the controller receives the command from the centralized controller. It displays the icon  . At this time, all the keys except the ON/OFF key are invalid.
- (2) After the controller receives the lock command, it displays the icon  . At this time, all keys are invalid.
- (3) In central or lock state, backlight is valid, press any keys to wake up screen.

Temperature compensation

- (1) This function is used to compensate for ambient temperature. In the state of off, and the backlight is lit up, long press FAN key for 10 seconds to enter temperature compensation interface. You can adjust the parameters with $+$ or $-$ key. After adjustment, you need to press MODE key to confirm change.
- (2) When it is Celsius, the range of parameter adjustment is $-4^{\circ}\text{C}\sim 4^{\circ}\text{C}$. When it is Fahrenheit, the range of parameter adjustment is $-8^{\circ}\text{F}\sim 8^{\circ}\text{F}$.
- (3) This function is valid only during collecting ambient temperature of wired controller.

Operation

Forced Cooling/Heating

- (1) After controller is in cooling mode and is turned off, long press ON/OFF key for 10 seconds to enter forced cooling function. At this time, controller will be turned on, and “LL” flashes in the middle area to indicate that the forced cooling function is turned on.
- (2) After controller is in heating mode and is turned off, long press ON/OFF key for 10 seconds to enter forced heating function. At this time, controller will be turned on, and “HH” flashes in the middle area to indicate that the forced heating function is turned on.
- (3) All keys are invalid except ON/OFF key under forced cooling/heating mode.
- (4) when the forced cooling/heating is set, press ON/OFF key to exit this function.

Operation

VIP (Only valid for part of models)

(1) Setting method:

In the state of off, when the backlight is lit up, long press \oplus key for 10 seconds to enter VIP function.

The timing display area displays whether there is a VIP in the system. 00 means none, 01 means yes, and the value is still displayed, indicating that it cannot be changed;

In the middle area displays the local VIP parameters, 00 represents the local non VIP and 01 represents the local VIP. Flashes if changes are allowed; If it cannot be changed, the display will be still.

Pressing \oplus or \ominus key to switch the parameters, and pressing the MODE key to confirm.

(2) In the Timer display area, 1 means the local VIP is turned on, and 0 means the local VIP is turned off;

(3) If VIP is not set in the outdoor unit system, any wired controller of indoor unit can be set with VIP function; if the outdoor unit system has set VIP function, only the VIP machine can be set up VIP on or off.

(4) After setting VIP function, if the indoor unit is sated VIP function, the main interface will display the characters "VIP"; if it is a non-VIP indoor unit, and when the mode of indoor unit is different from the VIP indoor unit, the controller will display the "Mode conflict" icon



(5) When switching between VIP and non-VIP, you need to exit the current Settings and enter again.

Operation

Wi-Fi (Only valid for part of models)

Keep pressing On/Off key for 10 seconds to enter Wi-Fi configuration function, Wi-Fi icon will flash. Then, the user can operate the mobile phone to configure. After the binding is successful, the Wi-Fi icon will still display.

Difference between the function of the Master wired controller and Slave wired controller

Comparison item	Master wired controller	Slave wired controller
Function	All functions are available	Only the following operations can be performed: (1) ON/OFF, Mode, Fan speed, Temperature setting, Swing, Energy saving, Clock function are available. (2) parameter inquiry and malfunction inquiry.




Operation

Dip switch

DIP switch	ON/OFF station	Function	Default setting
Sw1	ON	Slave wired controller	OFF
	OFF	Master wired controller	
Sw2	ON	Display ambient temperature	OFF
	OFF	Not display ambient temperature	
Sw3	ON	Collect ambient temperature from PCB of indoor unit	OFF
	OFF	Collect ambient temperature from wired controller	
Sw4	ON	Old protocol	OFF
	OFF	Self-adaption	

Wired Controller Wiring Instruction

Wiring Connections of Wire Controller



Notice:

For wired controller connection, please do follow the corresponding indoor unit installation manual's instruction.

Wired Controller Wiring Instruction

There are three methods to connect wired controller to the indoor units:

1. Group control shown as Figure A : One wired controller can control up to 16 indoor units. 3 pieces of polar wire must be used to connect the wired controller and the master unit (the indoor unit connected with wire controller directly). And other units connect to the master unit through 2 pieces or 3 pieces of polar wire depending on the indoor units, please do follow the corresponding indoor unit installation manual's instruction. For AC motor units, pls connect with B&C 2 wires; for DC motor units, pls connect with A & B & C 3 wires.
2. Individual control as shown Figure B: One wired controller controls one indoor unit, and the indoor unit connects to the wired controller through 3 pieces of polar wire.
3. Two wired controllers control one indoor unit as shown Figure C. Either one of wired controllers can be setas the master wired controller and the other as the slave wired controller. The connection between Master and slave wired controllers as well as wired controllers connecting to indoor units all requires the 3 pieces of polar wire.

Wired Controller Wiring Instruction

Communication wiring


Communication wiring length (m/ft)	Dimensions of wiring
<100m/328ft	0.3mm ² x3-core shielded wire (22AWG,3wire)
≥100m/328ft and <200m/656ft	0.5mm ² x3-core shielded wire (20AWG,3wire)
≥200m/656ft and <300m/984ft	0.75mm ² x3-core shielded wire (18AWG,3wire)

Note:

- One side of the shielded sheet of communication wire must be earthed.
- The total length of communication wire cannot exceed 300 meters.


Controller Installation

1.First, remove the top case from the bottom case.



Wired Controller Wiring Instruction

2. Put communication wire through the hole in the back cover.



3. Fix back cover to the holder. After that, connect communication wire to CON1 port of wired controller. Finally put the front cover of wired controller to back cover to complete the installation.

